



# Durascrim

**Polyester Reinforcing Fabric For Use With Duram Membranes And Coatings**

---

## Description

Open weave polyester reinforcing fabric for the use of reinforcing Duram waterproofing membranes.

Available in the following roll sizes:

- » 100mm x 10m
  - » 150mm x 10m
  - » 300mm x 10m
  - » 100mm x 50m
  - » 150mm x 50m
  - » 1.2m x 50m
- 

## Uses

As a reinforcing fabric, Duram Durascrim is suitable to use with the following Duram Membranes: Durabit EF, Durabit Reo, Durabit-Bitumen Free, Azcoflex, Pondseal, Duram 195 and Multithane.

Reinforcing membranes with Durascrim is recommended over joints, cracks, gaps and in corners or wherever additional tensile strength or membrane build up is desired.

---

## Suitable Surfaces

Refer to product data sheet for the particular Duram waterproofing product.

---

## Specification

The information contained in this product data sheet is typical but does not constitute a full specification as conditions and specific requirements may vary from project to project. The instructions should be considered as a minimum requirement but the applicator or contractor must use their skill, knowledge and experience to carry out additional works as may be necessary to meet the requirements of the project. Specification for specific projects should be sought from the Company in writing.

## Benefits and Advantages

By using Durascrim:

- Provides additional strength to waterproofing membranes.
- Allows greater product build up.

## Application

Apply 1st coat of the Duram membrane, usually at no less than 500 microns thick, and embed the Durascrim into wet coat. Apply a similar saturating coat over and working it in to the Durascrim ensuring that there are no wrinkles, folds or bubbles in fabric and sufficient product has been applied to cover the fabric. Allow to dry. Apply 1 to 2 additional coats at 500 microns thick and allow to dry.

Refer to product data sheets of the Duram membrane in question.

## Coverage

The stated average coverage rate may vary depending upon type, condition, porosity, texture of the surface and application technique.

Generally, at least 2 Lt per m<sup>2</sup> of product is needed to properly saturate and cover Durascrim.

## Colours

White.

## Storage

Keep in dry area.

For full safety data refer to the products Material Safety Data Sheet. Observe precautions as per label.

## Conditions of Use and Disclaimer

The information contained in this Material Data Sheet is given in good faith based upon our current knowledge and does not imply warranty, express or implied. The information is provided and the product is sold on the basis that the product is used for its intended purpose and is used in a proper workmanlike manner in accordance with the instructions of the Product Data Sheet in suitable and safe working conditions. Under no circumstances will the Company be liable for loss, consequential or otherwise, arising from the use of the product.

**DURAM PTY LTD** ABN 50 612 836 718

**The Ultimate in Waterproofing & Protective Coating Technology**

**Duram Offices:**

**NEW SOUTH WALES:** 51 Prince William Drive, Seven Hills, NSW 2147

Tel (02) 9624 4077 Fax: (02) 9624 4079

**QUEENSLAND:** Unit 4, 29 Collinsvale St Rocklea, QLD 4106

Tel (07) 3255 6478 Fax: (07) 3255 6258